
### I TOWER PEAK

# ADAPTER FOR DOUBLE LAYER RIDGE PIECE FOR TOWER

 Accessory that allows for lifeline assembly even on closed roofing, without the need for opening and adapting to any slope

• The TOWER PEAK adaptor makes it possible to provide safety for up to four workers



### CODES AND DIMENSIONS

CODE	material	<b>B</b> [mm] <i>[in]</i>	<b>H</b> [mm] <i>[in]</i>	<b>L</b> [mm] <i>[in]</i>	pcs
TOWERPEAK	S235JR zinc plated steel	100 4	30 1 3/16	350 13 3/4	1

#### COMPLEMENTARY PRODUCTS

no.	CODE	description	Ø	min. dimensions GL24h beam
			[mm]	[mm]
24	HBS	screw for timber	8	100 x 100


The values indicated are the result of experimental tests carried out under the supervision of third parties in accordance with the standard referred to. For a calculation report with minimum distances according to the relevant standard requirements, the substructure must be checked by a qualified engineer before installationo.

## I TOWER SLOPE

### FASTENING GUIDE FOR TOWER ON RAFTER

• It can be positioned at any point on the roof

• Due to the range of action from 50 to 100 cm, it can cover the most common distances between beams



### CODES AND DIMENSIONS

CODE	material	<b>B</b> [mm] <i>[in]</i>	<b>H</b> [mm] <i>[in]</i>	<b>L</b> [mm] <i>[in]</i>	pcs
TOWERSLOPE	S235JR zinc plated steel	100 4	20 13/16	1200 <i>47 1/4</i>	1

### COMPLEMENTARY PRODUCTS

no.	CODE	description	Ø	min. dimensions GL24h beam
			[mm]	[mm]
16	HBS	screw for timber	8	100 x 100

The values indicated are the result of experimental tests carried out under the supervision of third parties in accordance with the standard referred to. For a calculation report with minimum distances according to the relevant standard requirements, the substructure must be checked by a qualified engineer before installation.

